



Membrane patched from misplaced penetration.
VaproLiqui-Flash is applied to top and sides of membrane patch.

Flanges and fasteners should be completely covered with VaproLiqui-Flash
Minimum 1" of VaproLiqui-Flash onto flange or pipe penetration

For all penetrations: tool VaproLiqui-Flash evenly AT LEAST 2" onto the face and AT LEAST 1" out along all sides of the penetration

SLOPESHIELD SA[®]
SELF-ADHERED

VAPROLIQUI-FLASH[™]

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with VaproFlashing and VaproShield field membranes as a complete system.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 12/15/17

REF: 203

Always check www.VaproShield.com for the latest details and installation instructions