


WALLS & CEILINGS

THE VOICE OF THE INDUSTRY SINCE 1938™

PRODUCT FOCUS ON INSULATION
▶ PAGE 14

Tarlton and Son Inc. HELPS IN THE FIGHT AGAINST CANCER

▶ PAGE 19





Air Barrier
Weather Resistive Barrier



Adhesion Requirements



Project Details



Rain Screen Design



Cladding

BUILDING ENVELOPE: Converging multiple elements and trades

Contact VaproShield.com for expert technical guidance

Contact Us for a technical spec. review at VaproShield.com or 866-731-7663 Opt. 5

Do Your Research

FIVE TOPICS TO RESEARCH BEFORE ONE BIDS ON THAT WRB/AB PROJECT. BY DEREK MOULTON

As a field technician, I spend a large percentage of my time working with contractors. This involves attending preconstruction meetings, site visits and providing installation training on

mock-ups. From my experience, I would like to share with you some of the issues commonly encountered.

The first issue that should be confirmed is if the project has been specified as either a weather resistant barrier or an air barrier. In order to be classified as an air barrier, the membrane must be continuous, without breaks on all six sides of the building. If the details do not represent a continuous seal, then you have yourself a WRB. You would be surprised on the lack of clarity on this matter.

The second issue that should be reviewed in the specification is the matter of primer requirements. Do specific manufacturers require them, or is it left to the contractor to determine? If priming is required, what type? Water based or solvent? Is this primer compatible with the WRB/AB membrane? Many of the current vapor permeable polyolefin membranes can suffer damage when solvent-based primers or petrochemicals come in contact with the face of these membranes. Polyolefin membranes

include both polypropylene and polyester membranes. These primers also decrease and limit the permeability of the wall assembly.

Project details are a third issue one must review when putting together an estimate. From my experience at preconstruction meetings, these are the most commonly discussed areas that need clarification.

During these meetings I typically start from the bottom of the structure where the below grade to above grade materials connect. Many refer to this as the base of wall detail or through wall flashing area. This is one of the details frequently requiring amplification. This is due to questions arising anywhere from material compatibility to various contractor's scope of work.



Figure 1: An example of primer being applied to the face of a polyolefin membrane.



Figure 2: Here is an example of an untreated rough opening. A preconstruction meeting could have prevented this issue.



Figure 3: An example of wall to roof transition with material compatibility issues.



Figure 4: An example of an improperly detailed through wall flashing observed during a site observation walk.

Proper Sequencing Techniques

As we progress up the structure, the rough opening details would be the next topic. Do the details accurately represent proper sequencing techniques? An example of this would be the field

membrane being applied directly into the rough opening. Is this in accordance with the manufacturer's published installation guidelines? While on the topic of manufacturers, will there be multiple manufacturer's products being interfaced into the rough opening? Are

these products compatible? Does this create material warranty issues? Is your head spinning yet? One still has to consider proper shingle lapping techniques in the rough opening. Are the project details specific in regard to flashing components? Will reverse laps be cre-

Bond With

LARSEN

PRODUCTS CORP.

800.633.6668

www.larsenproducts.com

PLASTER-WELD®
The pink plaster-bonding agent

WELD-CRETE®
The pale blue concrete bonding agent

Over 60 years of superior performance in the field.



Do Your Research



Figure 5: An example of a wall installation with an improperly designed rain screen. Note the rigid insulation installed directly over the face of the WRB/AB preventing proper drainage.



Figure 6: An example of a properly designed and installed rain screen. Note the unimpeded drainage cavity.

ated directly above or below the rough opening? Keep in mind that rough opening areas are highly prone to construction defect or liability.


The last item to consider in regard to the project details would be the wall to roof transition. Many of the same issues described in the TWF and rough opening

repeat at this juncture of the wall assembly. This would apply especially to where the roof underlayment comes in contact with the face of the WRB/AB membrane. Many times these roof underlayments are asphaltic or may contain other petrochemicals, which previously stated, can damage polyolefin membranes.

Moving onto the fourth issue would be the topic of rainscreen design. This is currently a hot topic within the design community. To those not familiar with the term “rainscreen design”: the best way to describe the term would be as an unimpeded drainage plane behind the cladding with a ventilated



COLD-FORMED STEEL - ROOF • WALL • FLOOR



Aegis has a proprietary shape that brings your building the strongest Cold-Formed Steel on the market.

- 100% non-combustible Prime Steel
- Does not warp, shrink, split or twist with age
- Resistant to insects, mold and rot
- Wide variety of sizes and configurations
- Industry leading estimating and design software

314-851-2200
www.aegismetalframing.com

cavity. This type of wall assembly promotes maximum drainage out through the through-wall flashing. How do you create a rainscreen? This can be achieved by multiple design techniques which all involve providing a space between the face of the WRB/AB membrane and cladding. Some questions that have to be explored are as follows: Are the cladding attachments installed vertically or horizontally on the substrate? If applied horizontally, the cladding attachments will create a water dam due to the lack of a cavity. To reiterate, this is a somewhat new wall assembly technique for some parts of country. This topic has become a common discussion point at most preconstruction meetings.

The final topic to consider would be the matter of cladding systems specified for your project. Will the cladding be an open or closed joint system? If the closed joint cladding system is being utilized, are fastener requirements addressed? This type

AS A FORMER CONTRACTOR AND CURRENT FIELD TECHNICIAN FOR A MAJOR WRB/AB MANUFACTURER, I FEEL THESE TOPICS ARE CRUCIAL WHEN BIDDING PROJECTS.

of cladding system should not be directly fastened to the WRB/AB as a cavity should be required. Open joint systems have minimal gaps or reveals which allow UV exposure to the WRB/AB materials. Is this WRB/AB membrane material UV stable? What is the UV exposure limit for the membrane? Does it cover the life of the building?

As a former contractor and current field technician for a major WRB/AB manufacturer, I feel these topics

are crucial when bidding projects. As a contractor you take on a large portion of liability. With this in mind it is imperative that you work closely with the WRB/AB manufacturer's technical team. They should provide a service which includes product training and installation best practices. Are the current WRB/AB manufacturers that you work with providing your team with these items? **W&C**



— DEREK MOULTON —

Derek Moulton is technical representative at VaproShield. He has 18-plus years in masonry restoration. He has specialized in high-rise/swing-stage caulking, coatings and sealants.

HIGH PERFORMANCE
HPIP
INSULATION PROFESSIONALS

TO BETTER THE INSULATION INDUSTRY.

📞 605-219-5298
✉️ training@hpipros.org
🌐 www.hpipros.org
📺 @HPIPros

