


SLOPESHIELD® PLUS SELF-ADHERED

For Standing Seam Metal
 Roofing (Horizontal Material
 Application)



Step 1: Ensure sheathing is
 in “as-new” condition

PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 01/07/19

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions

SLOPESHIELD® PLUS SELF-ADHERED

For Standing Seam Metal
Roofing (Horizontal Material
Application)

SlopeShield Plus installed on eaves of roof, extending down to shingle over wall membrane

Sheathing in "as-new" condition



Walls with VaproShield membrane installed according to installation instructions

SlopeShield Plus installed around eaves, shingling over wall membrane



Step 2: Install SlopeFlashing around eaves, shingling over wall membrane

PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 01/07/19

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions

SLOPESHIELD® PLUS SELF-ADHERED

For Standing Seam Metal Roofing (Horizontal Material Application)



If desired adhesion is not attained between membranes due to site conditions, VaproShield recommends applying a bead of VaproBond as an additional solution to pressure rolling.

SlopeShield Plus Self-Adhered installed on gables of roof, extending down to shingle over wall membrane

SlopeShield Plus installed on eaves of roof, extending down to shingle over wall membrane

Walls with VaproShield membrane installed according to installation instructions

Step 3: Install SlopeFlashing on gables of roof, extending down to shingle over wall membrane

PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR


DATE: 01/07/19

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions

SLOPESHIELD® PLUS SELF-ADHERED

For Standing Seam Metal
Roofing (Horizontal Material
Application)



Step 4: Install metal flashing
(by others) over
SlopeFlashing at eaves

PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR


DATE: 01/07/19

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions

SLOPESHIELD® PLUS SELF-ADHERED

For Standing Seam Metal
Roofing (Horizontal Material
Application)



SlopeFlashing installed on gables of roof, extending down to shingle over wall membrane

First row of SlopeShield Plus installed at bottom of roof. SlopeShield Plus installs bottom to top to create shingle effect


Walls with VaproShield membrane installed according to installation instructions

<p>Step 5: Install first row of SlopeShield Plus Self-Adhered</p>	<p>PRODUCT DESCRIPTION SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material</p>	<p>DISCLAIMER Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is not the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.</p>
<p>DRAWN BY: AR DATE: 01/07/19</p>		

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions

Continue installation of SlopeShield Plus



Walls with VaproShield membrane installed according to installation instructions

Step 6: Install up roof, maintaining 3" minimum overlap between runs of roofing material

PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material

DISCLAIMER


Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 01/07/19

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions



Standing seam metal roofing installed over SlopeShield Plus Self-Adhered

Step 7: Install Standing seam metal roofing

PRODUCT DESCRIPTION

SlopeShield Plus Self-Adhered is a highly vapor permeable roofing underlayment Air Barrier (AB) material

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 01/07/19

REF: 214-A

Always check www.VaproShield.com for the latest details and installation instructions