

Correcting Reverse Lapping

As per Installation Instruction Best Practices:

- **WrapShield SA Self-Adhered** can be installed in a vertical or horizontal direction
- Always install in a “**weatherboard or shingle fashion**” with the lower courses lapped under the upper courses (See WrapShield SA Installation Instructions)
- However, VaproShield understands that proper sequencing is not always possible. In the event that a reverse lap condition is unavoidable the following procedure must be followed to ensure water holdout at the miss-lapped seam



Figure 1, Ensure the reversed lapped WrapShield SA Self-Adhered is bonded to the surface by utilizing a hand roller such as the Superior-Hand-Roller-80-R32-M.



Figure 2, On the upper reverse lap seam, apply a bead of VaproBond™ sealant the full length of the seam, as shown in Figure 3



Figure 3, apply a bead of VaproBond™ sealant the full length of the seam



Figure 4, Feather the bead of VaproBond™ using a hand trowel