


Rough Opening Flashing Sequence Step 1



RevealFlashing SA Self-Adhered properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

Note: Total of 11.75" of flashing should be used:

- 9" of flashing should be left on the face of the sheathing
- 6" of release film from the bottom of the flashing to be left attached for shingling over membrane.

VAPRO-SS FLASHING™

Step 1: Install VaproFlashing SA into sill with 2.75" folded into R.O. 9" left on face, with bottom 6" of release film to remain attached.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.


DRAWN BY: AR

DATE: 10/14/22

REF: 153-1

Always check www.VaproShield.com for the latest details and installation instructions

Rough Opening Flashing Sequence Step 2



RevealFlashing SA Self-Adhered properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.
Note: Total of 11.75" of flashing should be used:
- 9" of flashing should be left on the face of the sheathing
- 6" of release film from the bottom of the flashing to be left attached for shingling over membrane.

RevealFlashing SA Jamb Pieces applied directly to sheathing + folded 2.75" inside R.O.

VAPRO-SS FLASHING™

Step 2: Install jamb pieces with 2.75" folded into R.O. 9" to be left on face.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.


DRAWN BY: AR

DATE: 10/14/22

REF: 153-2

Always check www.VaproShield.com for the latest details and installation instructions

Rough Opening Flashing Sequence Step 3



RevealFlashing SA Self-Adhered properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.
 Note: Total of 11.75" of flashing should be used:
 - 9" of flashing should be left on the face of the sheathing
 - 6" of release film from the bottom of the flashing to be left attached for shingling over membrane.

RevealFlashing SA Jamb Pieces applied directly to sheathing + folded 2.75" inside R.O.

VAPRO-SS FLASHING™

Step 3: Install head piece with 2.75" folded into R.O. 9" to be left on face.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR


DATE: 10/14/22

REF: 153-3

Always check www.VaproShield.com for the latest details and installation instructions

Rough Opening Flashing Sequence

Step 4



VAPRO-SS FLASHING[™]

Step 4: Install Sill Piece of Vapro-SS Flashing with 2" on face and 3" upturned to jambs. See Cut Patterns Detail for more information and cut/fold instructions.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 10/14/22

REF: 153-4

Always check www.VaproShield.com for the latest details and installation instructions


Rough Opening Flashing Sequence

Step 5

RevealFlashing SA head piece applied directly to sheathing + folded 2.75" inside of R.O.

RevealFlashing SA Jamb Pieces applied directly to sheathing + folded 2.75" inside R.O.

Sheathing in "as new" condition



Notes:

a. To maintain continuity of air barrier system, while allowing for proper drainage at sill, a continuous interior window perimeter sealant joint with backer rod is required.

b. To determine width dimension of Vapro-SS Flashing required; Measure the depth the window projects into the rough opening from the exterior face of the wall and add 1/2".

c. Vapro-SS Flashing available in 4", 6", 9", 12", 18", or 24" widths by 50' length rolls

See Rough Opening Cut Patterns Detail for more information

RevealFlashing SA Self-Adhered properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.
Note: Total of 11.75" of flashing should be used:
- 9" of flashing should be left on the face of the sheathing
- 6" of release film from the bottom of the flashing to be left attached for shingling over membrane.

Vapro-SS Flashing installed in shingle fashion (sill, jambs, head) with 3" up-turned legs at sill and head + 2" on face; jambs are 2" onto the face.

VAPRO-SS FLASHING[™]

Step 5: Install Jamb Pieces of Vapro-SS Flashing with 2" on face. See Cut Patterns Detail for more information and cut/fold instructions.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR


DATE: 10/14/22

REF: 153-5

Always check www.VaproShield.com for the latest details and installation instructions

Rough Opening Flashing Sequence Step 6

Vapro-SS Flashing installed in shingle fashion (sill, jambs, head) with 3" up-turned legs at sill and head + 2" on face; jambs are 2" onto the face.



Notes:

a. To maintain continuity of air barrier system, while allowing for proper drainage at sill, a continuous interior window perimeter sealant joint with backer rod is required.

b. To determine width dimension of Vapro-SS Flashing required; Measure the depth the window projects into the rough opening from the exterior face of the wall and add 1/2".

c. Vapro-SS Flashing available in 4", 6", 9", 12", 18", or 24" widths by 50' length rolls

See Rough Opening Cut Patterns Detail for more information

VaproBond applied to perimeter of Vapro-SS Flashing on face

VaproBond 1/2" tooled fillet bead at each corner where inside of R.O. meets face of sheathing

VAPRO-SS FLASHING[™]

Step 6: Install Head Piece of Vapro-SS Flashing with 2" on face and 3" turned down onto jambs. See Cut Patterns Detail for more information and cut/fold instructions.

DRAWN BY: AR

DATE: 10/14/22

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)


DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is not the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

Rough Opening Flashing Sequence

Step 7

Head flashing (by others) over Vapro-SS
Flashing + embedded in VaproBond



Notes:

a. To maintain continuity of air barrier system, while allowing for proper drainage at sill, a continuous interior window perimeter sealant joint with backer rod is required.

b. To determine width dimension of Vapro-SS Flashing required; Measure the depth the window projects into the rough opening from the exterior face of the wall and add 1/2".

c. Vapro-SS Flashing available in 4", 6", 9", 12", 18", or 24" widths by 50' length rolls

See Rough Opening Cut Patterns Detail for more information

Immediately roll horizontal seams with floor roller to ensure full contact

RevealShield SA Self-Adhered field membrane installed underneath 6" flap of RevealFlashing SA to create shingle effect

RevealFlashing SA Self-Adhered properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

Note: Total of 11.75" of flashing should be used:

- 9" of flashing should be left on the face of the sheathing
- Remove release film from flashing and adhere bottom 6" to field membrane.

VaproBond applied to perimeter of Vapro-SS Flashing on face

VAPRO-SS FLASHING[™]

Step 7: Install field membrane underneath 6" flap of sill flashing to create shingle effect, remove release film, adhere to membrane

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is not the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.


DRAWN BY: AR

DATE: 10/14/22

REF: 153-7

Always check www.VaproShield.com for the latest details and installation instructions

Rough Opening Flashing Sequence Step 8



VAPRO-SS FLASHING™

Step 8: Install field membrane vertically to sheathing, maintaining 3" minimum overlap with R.O. flashing.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 10/14/22


REF: 153-8

Always check www.VaproShield.com for the latest details and installation instructions

Rough Opening Flashing Sequence Step 9

Commercial Window w/
Exterior perimeter
sealant joint + backer
rod (by others)

RevealShield SA Self-Adhered
installed over head flashing and
RevealFlashing SA



Immediately roll
horizontal
seams with floor
roller to ensure
full contact

RevealFlashing SA Self-Adhered properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

VaproBond applied to perimeter of Vapro-SS Flashing on face

RevealShield SA Self-Adhered field membrane installed vertically with minimum 3" overlap

VAPRO-SS FLASHING[™]
Step 1: Install field membrane over metal head flashing, maintaining 3" minimum overlap to adjacent field membrane.

PRODUCT DESCRIPTION

Vapro-SS Flashing has been designed with a flexible 2 mil sheet of type 304 stainless steel, 8 mils of butyl adhesive and a siliconized release liner. Vapro-SS Flashing is a self-adhering metal flashing that offers best in class puncture and tear resistance. It can be applied from 20°F (-6°C) to 170°F (77°C) and stays stable and air tight from -70°F (21°C) to 200°F (93°C)

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 10/14/22

REF: 153-9

Always check www.VaproShield.com for the latest details and installation instructions