


Step 1: Window Rough Opening Flashing Sequence



WrapFlashing properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

Note: Total of 11.75" of flashing should be used:

- 9" of flashing should be left on the face of the sheathing

WRAPSHIELD® IT INTEGRATED TAPE

Step 1: Inspect rough opening, Install WrapFlashing to Sill of R.O. with 2.75" folded inside R.O. and 9" left on face.

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 06.24.16


REF: 163-1

Always check www.VaproShield.com for the latest details and installation instructions

Step 2: Commercial Window RO Flashing System

WrapFlashing jamb pieces properly shingled, over sill piece and folded 2.75" inside of R.O.

Sheathing in "as new" condition



WrapFlashing properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

Note: Total of 11.75" of flashing should be used:

- 9" of flashing should be left on the face of the sheathing

WRAPSHIELD® IT INTEGRATED TAPE

Step 2: Install WrapFlashing to Jambes of R.O. with 2.75" folded inside R.O. and 9" left on face, shingled over Sill piece.

DRAWN BY: AR

DATE: 06.24.16

PRODUCT DESCRIPTION


VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

Step 3: Commercial Window RO Flashing System



WrapFlashing properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

Note: Total of 11.75" of flashing should be used:

- 9" of flashing should be left on the face of the sheathing

WRAPSHIELD® IT INTEGRATED TAPE

Step 3: Install WrapFlashing to Head of R.O. with 2.75" folded inside R.O. and 9" left on face, shingled over Jamb pieces.

DRAWN BY: AR

DATE: 06.24.16

PRODUCT DESCRIPTION


VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

Step 4: Commercial Window RO Flashing System



WrapFlashing properly shingled; applied directly to sheathing + folded 2.75" inside of R.O.

Note: Total of 11.75" of flashing should be used:

- 9" of flashing should be left on the face of the sheathing

Step 4: Apply VaproLiqui-Flash to inside of R.O. (full coverage) and 1" on face. Refer to VaproLiqui-Flash Installation page on VaproShield.com.
VaproShield.com/products/window-flashing-elements/vaproliqui-flash/installation

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.


DRAWN BY: AR

DATE: 06.24.16

REF: 163-4

Always check www.VaproShield.com for the latest details and installation instructions

Step 5: Commercial Window RO Flashing System



WRAPSHIELD® IT INTEGRATED TAPE

Step 5: Install field membrane horizontally, lining up with bottom edge of VaproLiqui-Flash or spanning across rough opening

DRAWN BY: AR

DATE: 06.24.16

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

Step 6: Commercial Window RO Flashing System



WRAPSHIELD® IT INTEGRATED TAPE

Step 6: Cut out section of field membrane to expose covered rough opening and 1" of VaproLiqui-Flash on face

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 06.24.16


REF: 163-6

Always check www.VaproShield.com for the latest details and installation instructions

Step 7: Commercial Window RO Flashing System

VaproLiqui-Flash full-coverage inside rough opening + 1" on face
See VaproLiqui-Flash Installation Instructions on VaproShield.com

Sheathing in "as new" condition



WrapShield IT Integrated Tape installed horizontally

- Field membrane shingled under jamb and sill flashing on upper window
- Field membrane with R.O. section cut out shingled under jamb and sill flashing

WRAPSHIELD® IT INTEGRATED TAPE

Step 7: Shingle field membrane under WrapFlashing sill and jamb pieces.

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

DRAWN BY: AR

DATE: 06.24.16


REF: 163-7

Always check www.VaproShield.com for the latest details and installation instructions

Step 8: Commercial Window RO Flashing System

VaproLiqui-Flash full-coverage inside rough opening + 1" on face
See VaproLiqui-Flash Installation Instructions on VaproShield.com

- WrapShield IT Integrated Tape installed horizontally
- Field membrane cut flush with edge of R.O.
- **Left unattached until window and head flashing are installed**



WRAPSHIELD® IT INTEGRATED TAPE

Step 8: Install field membrane horizontally, lining up integrated tape seams. Rough openings should be cut out, with VaproLiqui-Flash covered.

DRAWN BY: AR

DATE: 06.24.16

PRODUCT DESCRIPTION

VaproLiqui-Flash is a liquid applied, vapor permeable, waterproof, air barrier flashing system component for window and door rough openings. VaproLiquiFlash is designed to work with WrapFlashing and VaproShield field membranes as a complete system.

WrapShield IT Integrated Tape is a vapor permeable, weather resistive air barrier membrane with integrated tape at the horizontal seams.

DISCLAIMER

Detail sketch is generic, representing suggested best practices for VaproShield materials, and does not represent a specific job site condition and therefore may not be applicable to certain projects. Detail sketch is designed for use as a reference and must be approved by the designer/ consultant of record for each project prior to installation by the subcontractor. Changes and approvals of VaproShield details are the sole responsibility of the designer/consultant of record. VaproShield is **not** the designer of record for building enclosure details and takes no responsibility for the accuracy or interpretation of actual project site conditions.

REF: 163-8

Always check www.VaproShield.com for the latest details and installation instructions