


## Nail Flange Window Rough Opening Flashing: Exploded

1.) WrapFlashing SA Self Adhered Sill Piece applied directly to sheathing + installed 2.75" inside of R.O. Release film to be left on bottom 6" of flashing to create shingle effect with field membrane

2.) WrapFlashing SA Self Adhered Jamb Pieces applied directly to sheathing at edge of rough opening and outer edge + installed 2.75" inside of R.O.

3.) WrapFlashing SA Self Adhered Head Piece applied directly to sheathing at edge of rough opening and top edge + installed 2.75" inside of R.O.

4.) VaproBond @ inside rough opening + 1"on face



- 6.) Window with Nailing Flange
- 7.) VaproBond Sealant @ head, left, and right jamb flanges



VaproShield LLC | 915 26th Ave. N.W. Suite C5 | Gig Harbor, WA 98335 | Toll Free: 1.866.731.7663 | www.VaproShield.com | © VaproShield 6/28/2017