

VaproFlashing SA

a self-adhered air, water and vapor barrier flashing
Product No. 12" 42506090, 6" 42504890, 4" 42504590



Compatibility

- Exterior Gypsum Sheathing
- Rigid Insulation
- OSB
- Concrete
- Brick
- Plywood
- Metal (Steel, Aluminum)
- Fiberglass Window and Door Frames
- Wood Blocking

Installation

STORAGE AND HANDLING

Store material rolls on end in original packaging. Protect rolls from direct sunlight and inclement weather until ready for use.

PREPARATION

All surfaces must be dry, sound, clean, "as new" condition, and free of oil, grease, dirt, excess mortar, or other contaminants detrimental to the adhesion of the water resistive air barrier membrane and flashings.

Fill voids and gaps in substrate greater than 7/8 inch (22.2 mm) in width to provide an even surface.

INSTALLATION

Use roller to activate pressure-sensitive adhesive.

Best practice is to cover flashing as soon as practical.

DETAILS

Visit www.VaproShield.com for complete installation instructions and details.


LIMITATIONS

VaproFlashing SA should be covered within 12 months of installation. Minimum recommended application temperature of 20°F (-6°C) and rising. VaproFlashing SA is installed on most substrates without primer. Specific jobsite conditions may require additional surface preparation with primer, contact VaproShield Technical.

Technical Data

PHYSICAL PROPERTIES	
PROPERTY	RESULT
Color	White
Size	12" x 100', 100 S/F (.3m x 30.5m, 9.3 S/M), 8 lbs (3.6 kg) 6" x 100' (0.15m x 30.5m) 50 S/F (4.6 S/M), 4 lbs (1.8 kg) 4" x 100' (0.10m x 30.5m) 33.3 S/F (3.1 S/M), 3 lbs (1.4 kg)
Thickness	0.33 mm (13 mil)
Packaging	Individual Wrapped Rolls
UV Exposure	365 Days
Application Temperature	20°F (-6.6°C) - 180°F (82°C)
Service Temperature	-30°F to 200°F (-34°C to 93°C)
Warranty	20 year material warranty

Rough Opening Detail



- A** Install VaproFlashing SA directly to the sheathing and fold inside the rough opening.
- B** Tool a bead of VaproBond or other VaproShield approved sealant at all corner seams.
- C** Release film from the bottom of the flashing to be left attached for shingling over membrane.